

***VIPCOO VS6 Pro***

***VIPCOO***

U S E R M A N U A L

# USER MANUAL

# VIPCOO

PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE RIDING



Scan QR Code Or Enter URL for Online Installation Video

[https://www.youtube.com/playlist?list=PLQ1eamCE\\_z6hOpcCIhBsLR19rD13hiNOV](https://www.youtube.com/playlist?list=PLQ1eamCE_z6hOpcCIhBsLR19rD13hiNOV)



# Read This Manual Before Using

Why Is It Necessary To Read This Manual Before Operating?

- 1、 This manual was written to help you understand the proper use and maintenance of the VIPCOO line of Electric Scooter.
- 2、 It is important to understand the functions and features of the new VIPCOO before operating it as it will allow you to enjoy it from every ride.



## Disclaimer & Warning

During the cycling process, comprehensive safety measures should be taken, and risk awareness and good judgment should be maintained at all times to avoid injuries as much as possible.

- The user must be an adult.
- The responsibility for VIPCOO maintenance is yours! Proper and frequent maintenance will reduce risks of injuries.
- Please wear a helmet, protective gear, and other safety measures when riding.
- Always follow local laws and regulations.
- Do not perform stunts, spins or jumps; if you insist on doing these dangerous actions, please take full protective measures.

# CONTENT

Product & Component Display.....	1~2
Product Parameters .....	3
Products & Accessories .....	4
Product Installation .....	5~6
Product Folding .....	7
Power on and off & Button Function Introduction.....	8
Safe Driving Warning .....	9~10
Battery & Charging .....	11~12
After Sales .....	13
Limited Warranty .....	14
Warranty Card .....	15

# Product & Component Display




01: Front brake lever  
02: Hook  
03: Stem lock latch  
04: Front stem  
05: Folding lock bolt  
06: Headlights

07: Front mud guard  
08: Front Motor  
09: Front suspension  
10: Charging port  
11: Turn signal  
12: Side light strip

13: Brake light & Turn Signal Light  
14: Kick stand  
15: Rear pedal  
16: Rear mudguard  
17: Rear suspension  
18: Rear Motor

# Product & Component Display



01: Rear brake lever

02: Turn signal switch

03: Dual drive mode switch

04: Horn

05: Speed mode

06: Dual drive

07: Voltage

08: Light

09: Speed

10: Battery

11: Turn signal

12: Power button

13: Minus

14: Plus

15: Finger throttle

16: Front brake lever

# Product Parameters

Model	VC-VS6 Pro	Tire Size	10 inch
Battery	52V/20.8Ah	Tyre Type	Tubeless Tire
Power	1200w*2	Charging time	9~10hours
Display Screen	Color	Frame Material	Aluminium Alloy
Range	50-65KM	Net Weight	31KG
Max Load	120KG	Gross Weight	35KG
Brake	Front and rear disc brake	Package Size	125.5*23*58.5cm
Light	Front LED headlights, side light strips, turn signal and tail lights		
Adapter	Input 100-240V~50/60Hz 2.5A, Output 58.8V 2.0A		

The weight of the tester is 85kg, speed under 25km/h on single drive and the range of the flat road test is 50-65km. The length of the range depends on the weight of the rider, the riding conditions, and the temperature; If the weight of the cyclist exceeds 85kg, the road conditions are rough, and the temperature is low, the range will be correspondingly shortened.

# Products & Accessories



SERIAL NUMBER	ITEM	QUANTITY
1	Instructions	1
2	Charger	1
3	Toolkit	1
4	Band	1
5	NFC card	3

# Product Installation

- 01** Open the package, you should receive these items



- 02** Loosen the stem folding lock bolt until the limit stop module completely exits the limit slot



- 03** Lift the stem to unfold the scooter



- 04** Fully unfold the scooter



- 05** Tighten the folding lock bolt so the limit stop module goes back into the limit slot by turning it clockwise



- 06** Loosen and remove the 4 screws on the bottom clamp plate and set them aside



07

Place the top clamp plate with display mounting on it on top of the handlebar



08

Lift the display and insert those 4 screws into the screw holes of the clamp fastener



09

Adjust the handlebar to a comfortable angle then tighten these 4 screws



10

Put down the display



11

Tighten the fixing screw of the display on its back



12

Installation complete



# Product Folding

01

Loosen the stem folding lock bolt until the limit stop module completely exits the limit slot



02

Open the stem locking latch



03

Unlock the safety lock



04

Push down the stem and hook the front segment of the rear mud guard with the hook



05

Push down the stem and hook the front segment of the rear mud guard with the hook



06

Folding complete



# Power on and off & Button Function Introduction

Long press the power  button to turn on the scooter's dashboard and enter the password input interface. Use the plus  and minus  buttons to adjust numbers. Press the power  button to confirm each digit. The default password is 0000. After entering the password, long press the power  button to start the scooter (you can also tap the NFC card  to the dashboard during the password input interface for quick startup).

Short press the plus  or minus  button to shift gears up or down.

Long press the plus  button to turn the headlight on or off. Double click  to turn on and off the side light strips

Hold the minus  button while pushing the scooter to activate push-assist mode, which moves the scooter forward at 4 km/h. Release the minus button to stop boost mode immediately.

Tilt the turn switch  to the left to activate the left turn signal; tilt it left again to turn off the left signal. Tilt the turn switch to the right to activate the right turn signal; tilt it right again to turn off the right signal.

Press the dual-drive  button—the red light on the button indicates dual-drive mode is active. Press it again (light off) to switch to single-drive mode.

After unlocking, please wear a helmet and protective gear before cycling, and ensure that all functions of the scooter are normal before starting your cycling.

# Safe Driving Warning

Certain countries of regions require safety devices or gear. It is your responsibility to know the state laws and follow them. However, we strongly recommend safety gears to be donned before operating the device.

TIRE AIR PRESSURE: THE TIRE IS PRESSURIZED TO THE STANDARD VALUE ON THE TIRE

## SAFETY GEAR

Helmet: Most common and serious injuries from riding are head injuries. This can be prevented by donning a helmet. You must wear a helmet when riding the VIPCOO Scooter. The helmet must be worn according to their instruction.

## MECHANICAL SAFETY

Before using the VIPCOO Scooter:

- 1) Always perform a visual inspection of all screws and nuts are tight and in place. If anything is amiss or missing and you are unsure, please contact the seller to confirm safety before use.
- 2) Check the tires and wheels and that it is not showing signs of wear and tear; Always ensure that the brake mechanism is not touching the wheels and allows free spinning.
- 3) Always perform mechanical checks of brakes and other parts of the scooter that allows visibility, safety and functionality of the scooter to be.

## RIDING SAFETY

- 1) Put one foot on the board and the other on the ground.
- 2) Press the accelerator lever slightly, and the scooter accelerates. Put both feet on the board after you can keep balance. Press down the lever to speed the scooter up.
- 3) Release the accelerator to slow down, Squeeze the brake lever at the left handle bar to stop the scooter.
- 4) Tilt your body slightly to the side you want to turn, and slowly turn the handlebars.
- 5) Do not ride in the rain.
- 6) Please slow down before speed bump, potholes and other uneven surface. Bend your knees to steady yourself on the complex road.
- 7) Do not accelerate downhill.
- 8) Do not hang heavy objects such as backpack on the handlebars.
- 9) Do not press the accelerator when you walk on foot.
- 10) Do not ride on the roadways.
- 11) Do not turn suddenly at high speed.
- 12) No riding to water above 2cm.
- 13) No riding with another person or a child.
- 14) Do not step on the fender.
- 15) Do not touch the disk brake after braking frequently, it will be very hot!
- 16) Do not release the handlebars while riding!
- 17) No riding upstairs or downstairs!

# Battery & Charging

## BATTERY

- **Do not charge indoors.**
- Do not turn on and operate the scooter while charging.
- Keep the battery away from children, pets or direct heat.
- Do not expose the battery to high temperature and pressure.
- Please use the charger included with the scooter for charging.
- Please do not throw away batteries at will to avoid polluting the environment.
- Do not store the scooter over a long period of time with an almost empty battery.
- From time to time, discharge the battery by riding. Have the battery recharge again and make sure to not leave battery fully empty.

Do not charge if the scooter has the following conditions occur:

- The battery leaks.
- The battery is damaged.
- The battery heats up or is deformed.
- The bottom or overall of the deck overheats.

The use, storage or charging of the battery outside specified limits may result in the annulment of the warranty, battery damage and an effective battery charging.

# Battery & Charging

## First Charge

It is important to fully charge the battery before your first use of the scooter.

---

Your scooter's battery comes with these built-in features:

1. Balanced charging protection: During charging, the battery automatically balances the voltage among the internal cells to protect each cell.
2. Over-charging protection: The battery stops charging automatically when full to protect against damage.
3. Over current protection: The battery automatically stops charging if the voltage is higher than prescribed voltage to protect the battery.
4. Over discharging protection: The battery automatically stops discharging when its voltage drops below Under voltage value to protect the battery.
5. Short-circuit protection: the battery automatically stops output in the case of a short-circuit.

## How to charge

---

1. **Do not charge indoors.**
2. Ensure that scooter is **TURNED OFF**. Connect external power charger to scooter.
3. Connect charger to electrical outlet, then turn on the power of electrical outlet.
4. Do not charge the batteries in temperatures below 5 °C or above 40 °C. The battery may stop the charging process.
5. The charger lights up RED- The battery is charging. The charger lights up GREEN – The battery is fully charged.
6. After the battery is fully charged, please unplug the charger in time.

# After Sales

Dear customer,

Thank you for choosing our product! To ensure that you can install and use our product smoothly, we strongly recommend that you visit our official website to view the related video installation tutorials and after-sales parts replacement videos.

On our official website, you can find detailed video tutorials that guide you on how to correctly install and use our product. In addition, we also provide after-sales parts replacement videos to ensure that you can correctly perform the replacement when needed.

We hope these videos will help you better understand and use our product. If you still have questions or concerns after watching the videos, please feel free to contact our customer service team, and we will be happy to assist you.

Thank you again for your purchase and support!

Wishing you a pleasant user experience!

The logo for VIPCOO, featuring the brand name in a bold, italicized, black sans-serif font.

<https://www.vipcoo.com>



<https://www.youtube.com/@VIPCOO>

# Limited Warranty

BY USING THIS PRODUCT YOU AGREE TO THIS LIMITED WARRANTY.  
PLEASE READ THIS LIMITED WARRANTY CAREFULLY.

To benefit from the limited warranty, the customer is advised to read VIPCOO Warranty terms together with the “care and maintenance” sections provided in the user manual. This limited warranty applies to the extent permitted by law and unless restricted or prohibited by law.

Attentions for warranty Faults caused by any of following causes are not within the scope of warranty:

1. Failed to maintain according to this user manual.
2. Product damage or defects caused by improper driver operation.
3. Damage caused by misuse, traffic accident or accidental collision.
4. Damage caused by riding on abnormal roads or accidental collision.
5. Damage of the vehicle caused by natural disaster or irresistible force.
6. Products which have had their serial numbers removed or tampered with.
7. Defects or malfunctions of the product not notified by customer during the Warranty Period.
8. Products used for commercial purposes including but not limited to leasing/hiring, use in competitions etc.
9. Performing high-risk actions such as stunts, spinning, or jumping lead to rapid aging or malfunction of the product.
10. Expose this product under blazing sun or outdoor for along time,as that will speed up the aging process of the product and cause malfunction.
11. Defects or damages from improper storage, exposure to moisture or dampness, modifications, connections, repairs (except as carried out by VIPCOO or its authorised centres), misuse, neglect, abuse, accident, alteration, improper installation, or other acts which are not the fault of VIPCOO , including damage caused by dropping, blown fuses, liquid entering the interior of theproduct.

**PLEASE ALWAYS KEEP THE BOX FOR ANY POSSIBLE FUTURE AFTER-SALES SHIPMENT**

Warranty Card

Dear user, Thanks for using our electric scooter. Please fill in the form below clearly for sake of better after-sale services.

User	Name		Workplace	
	Tel			
	Add			
Date of Purchase			Serial number	
Model			VIN	
Invoice Number			Battery serial number	
Distributor	Name			
	Contact			
Note				

**Shenzhen Tianjia International Supply Chain Co.,Ltd.**

Address: Room 505, building 1, Liuwei business center, Bantian street, Longgang District,



Shenzhen China



WhatsApp: +8613612953725



Customer support: support@vipcoo.com



Official website: www.vipcoo.com

**VIPCOO**

**VIPCOO**